


SG485-2CAN

COMMUNICATION INTERFACE CONVERSION MODULE

USER MANUAL



郑州众智科技股份有限公司 SMARTGEN(ZHENGZHOU)TECHNOLOGY CO.,LTD.



SmartGen众智 Chinese trademark

SmartGen English trademark

SmartGen – make your generator *smart* SmartGen Technology Co., Ltd. No.28 Jinsuo Road Zhengzhou Henan Province P. R. China Tel: +86-371-67988888/67981888/67992951 +86-371-67981000(overseas) Fax: +86-371-67992952 Web: www.smartgen.com.cn/ www.smartgen.cn/ Email: sales@smartgen.cn

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to Smartgen Technology at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.

SmartGen Technology reserves the right to change the contents of this document without prior notice.

Table 1 Software Version

Date	Version	Note
2021-08-18	1.0	Original release.
2021-11-06	1.1	Modify some descriptions.
2021-01-24	1.2	Modify the error in Fig.2.



CONTENTS

1	OVERVIEW	4
2	PERFORMANCE AND CHARACTERISTICS	4
3	SPECIFICATION	4
4	WIRING	5
5	ELECTRICAL CONNECTION DIAGRAM	6
6	OVERALL DIMENSION AND INSTALLATION	7



1 OVERVIEW

SG485-2CAN is a communication interface conversion module, which has 4 interfaces, namely RS485 host interface, RS485 slave interface and two CANBUS interfaces. It is used to convert 1# RS485 interface to 2# CANBUS interfaces and 1# RS485 interface by DIP switch to set address, providing convenience for customers to monitor and collect data.

2 PERFORMANCE AND CHARACTERISTICS

Its main characteristics are as follows:

- With 32-bit ARM SCM, high hardware integration, improved reliability;
- 35mm guide rail installation method;
- Modular design and pluggable connection terminals; compact structure with easy mounting.

3 SPECIFICATION

Items	Contents				
Working Voltage	DC8V~DC35V				
	Baud rate: 9600bps				
RS485 Interface	Stop bit: 2-bit				
	Parity bit: None				
CANBUS Interface	250kbps				
Case Dimension	107.6mmx93.0mmx60.7mm (LxWxH)				
Working Temperature	(-40~+70)°C				
Working Humidity	(20~93)%RH				
Storage Temperature	(-40~+80)°C				
Protection Level	IP20				
Weight	0.2kg				

Table 2 Performance Parameters



4 WIRING




Fig.1 Mask Diagram

Table 3 Indicators Description

No.	Indicator	Description
1.	POWER	Power indicator, always on when powered on.
2.	ТХ	RS485/CANBUS interface TX indicator, it flashes 100ms when sending data.
3.	RX	RS485/CANBUS interface RX indicator, it flashes 100ms when receiving data.

Table 4 Wiring Terminals Description


No.	Function		Cable Size	Remark					
1.	В-		1.0mm ²	DC power negative.					
2.	B+		1.0mm ²	DC power positive.					
3.		B(-)		RS485 host interface communicates with					
4.	RS485(1)	A(+)	0.5mm ²	controller, TR can be short connected with A(+), which is equivalent to connecting 120Ω matching resistance between A(+) and B(-).					
5.		TR							
6.		B(-)	0.5mm ²	RS485 slave interface communicates with PC					
7.	RS485(2)	A(+)		monitoring interface, TR can be short connected with A(+), which is equivalent to connecting 120Ω matching resistance between A(+) and B(-).					
8.	(_)	TR							
9.		TR	0.5mm ²	CANBUS interface, TR can be short connected with CANH, which is equivalent to connecting					
10.	CAN(1)	CANL							
11.		CANH	0.01111	120Ω matching resistance between CANL and CANH.					
12.		TR	0.5mm ²	CANBUS interface, TR can be short connected with CANH, which is equivalent to connecting 120Ω matching resistance between CANL and CANH.					
13.	CAN(2)	CANL							
14.		CANH							
/	USB Software download and upgrade interface		/	/					



Table 5 Communication Address Setting

Communication Address Setting								
Address	RS485(2)			Reserved				
DIP Switch No.	1	2	3	4	5	6	7	8
	000: 1							
O a market and in a	001: 2							
Corresponding	010: 3							
relation between dial switch combination	011: 4			Keep the DIP address, it has no effect on communication no matter how it is set.				
and communication	100: 5							
address	101: 6							
auuless	110: 7							
	111: 8							


5 ELECTRICAL CONNECTION DIAGRAM








6 OVERALL DIMENSION AND INSTALLATION








Fig.3 Overall Dimension and Installation (Unit: mm)